



RST INSTRUMENTS LTD.

RS232 to RS485 Adaptor
Instruction Manual

RST Instruments Ltd.
11545 Kingston St
Maple Ridge, BC Canada V2X 0Z5
Tel: (604) 540-1100
Fax: (604) 540-1005
Email: Info@rstinstruments.com

RS232 to RS485 Adaptor Instruction Manual

Although all efforts have been made to ensure the accuracy and completeness of the information contained in this document, RST Instruments reserves the right to change the information at any time and assumes no liability for its accuracy.

Product: RS232 to RS485 Adaptor
Instruction Manual

Document number: ELM0051C RS232 to RS485 Instruction Manual.doc

Revision: C

Date: April 2, 2012

TABLE OF CONTENTS

1	INTRODUCTION	1
2	ADAPTOR SET-UP	1
3	COMMUNICATION PORT SETTINGS	3
3.1	RS232 PORT	3
3.2	RS485 PORT	3
4	ADVANCED COMMANDS	3
4.1	COMMAND FORMAT.....	3
4.2	COMMANDS.....	3
4.2.1	TR	3
4.2.2	SR	4
4.3	TYPICAL READING SEQUENCE.....	4
4.4	SPECIAL COMMANDS.....	4
4.4.1	MODE.....	4
4.4.2	BAUD	5
5	CONTACT US.....	6

LIST OF FIGURES

Figure 1 – RS485 Terminal Connections.....	1
Figure 2 – RS232 Terminal Connections.....	2

1 INTRODUCTION

RST RS232 to RS485 Adaptor has been developed to interface instrumentation utilizing RS485 communication to monitoring equipment via RS232 port.

2 ADAPTOR SET-UP

The adapter requires 7 – 15 DC power.

RS485 Terminal




Figure 1 – RS485 Terminal Connections

1. Power
2. A
3. B
4. Ground

RS232 Terminal




Figure 2 – RS232 Terminal Connections

The RS232 terminal can be connected to a PC computer or a logger.

The wiring is as follows.

1. Power (7 – 15 Volts)
2. RX (RS232 9-pin D-Sub pin 2)
3. TX (RS232 9-pin D-Sub pin 3)
4. Ground (RS232 9-pin D-Sub pin 5) & Power Ground

3 COMMUNICATION PORT SETTINGS

3.1 RS232 PORT

The RS232 COM port settings are as follows:

Baud 115200, 8 data bits, no parity, 1 stop bit.

The RS232 port baud can be changed if needed, see section 4.4.2 for details.

3.2 RS485 PORT

The RS485 port baud is factory fixed at 9600.

4 ADVANCED COMMANDS

When the RS232 to RS485 Adapter is connected to PC computer running communication software (HyperTerminal), various commands can be used to retrieve information from connected instruments. Following is a list of commands supported by RST Digital Tilt Meter.

4.1 COMMAND FORMAT

All commands have the following format: @@#####_ComandStringCR

@@	= Address detect mode character string
#####	= Address in decimal format, 0-9
_	= Character to terminate address, char not in 0-9
ComandString	= Command to be processed
CR	= Carriage return, hex 0x0D. Command termination character.

Note

In the case only one device is connected, the special address **65535** can be used to access the device.

4.2 COMMANDS

There are two commands required to retrieve a set of readings from the Digital Tilt Bus.

TR = Take a set of readings

SR = Send the last set of readings

Reading set = reading from tilt sensor A, tilt sensor B and temperature.

4.2.1 TR

The TR command causes the Digital Tilt Bus to take a set of sensors reading and store the set in memory. Only the most current reading set is stored. The stored reading set is maintained until power is removed from the Digital Tilt Bus or a new reading set is taken.

TR	= Take a single reading set then enter low power mode.
TR 1	= Put sensors in continuous reading mode. Sensors do not power down
TR 0	= Take a single reading then enter low power mode. Terminate continuous mode.

Sample Command: @@12345 TR 1CR
 Return String: TR 1CR

4.2.2 SR

The SR command causes the Digital Tilt Bus to send the latest reading set. The reading set will not be updated unless continuous reading mode has been entered. If the TR has not been processed, the entries in the returned reading set defaults to 0. The entries are comma separated.

Sample Command: @@12345 SRCR
 Return String: SR,ReadingA,ReadingB,Temperature CR
 ReadingA Format: #.#####
 ReadingB Format: #.#####
 Temp Format: #.##
 Default Reading SR,0.00000,0.00000,0.00

Error Response:

If an invalid address is entered, there will no response. If an invalid command is entered, the echoed command followed by a '?' will be sent.

4.3 TYPICAL READING SEQUENCE

- Power on
- Wait 600ms
- Send TR command: Wait for CR after echo.
- Uni-Axial: Wait 1300 ms; Bi-Axial: Wait 2100 ms.
- Send SR command: Wait for CR after echo and data.

Update rate in continuous mode

Uni-Axial = 750 ms
 Bi-Axial = 1650 ms

4.4 SPECIAL COMMANDS

4.4.1 MODE

The MODE command is used to switch the functionality of the adaptor. For RS232 to RS485 use the following to ensure the correct configuration:

MODE 0CR

Since the commands are passed through the adaptor, typed commands are not echoed back.

To verify the communication, type the following command to switch to another mode:

MODE 1CR

The adaptor should respond with "RST Thermarray" to indicate proper communication. Lack of response indicates communication problem. See chapter 2 to verify connections and chapter 3 for communication settings.

Ensure that the adaptor is in RS232 to RS485 mode by typing:

MODE 0CR

4.4.2 BAUD

The BAUD command will change the RS232 COM port baud. In order to use the BAUD command, adapter needs to be switched into different mode. Follow the sequence below to change baud:

MODE 1**CR**

BAUD <baud rate>**CR**

The supported <baud rate> is either 115200 or 9600.

After changing baud rate, send the MODE command again to switch the adapter to RS232 to RS485.

MODE 0**CR**

5 CONTACT US

For sales information contact: sales@rstinstruments.com

For technical support contact: rst_support@rstinstruments.com

Head Office:

11545 Kingston St
Maple Ridge, BC
Canada V2X 0Z5

Our office hours are: 8:30am – 5:00pm PST
Monday – Friday (excluding holidays)

Telephone: 604-540-1100
Facsimile: 604-540-1005
Toll Free: 1-800-665-5599
Website: www.rstinstruments.com